





**Teacup stacking (fits 100F)**  
3AZT001U 6¼oz 18cl  
3AZT002U 8oz 23cl




**Tea/breakfast saucer**  
3AZT100F



**Plate (decorated rim only)**  
3QVW210C 6¾" 16.2cm  
3QVW230C 8" 20.5cm  
3QVW240C 9" 23cm  
3QVW260C 10" 25.4cm



**Soup bowl (unhandled)**  
3AZT591X 11oz 31cl




**Oatmeal/salad bowl**  
3AZT337X 6½" 16.5cm 16¼oz 46.1cl



**Teacup low (fits 101X)**  
3AZT037X 7½oz 21cl



**After dinner cup stacking (fits 121X)**  
3AZT050U 3½oz 10cl



**After dinner cup (fits 121X)**  
3AZT060X 3½oz 9.5cl



**Café au lait cup (fits 101X)**  
3AZT099X 11oz 31cl




**Café au lait saucer**  
3AZT101X



**After dinner saucer**  
3AZT121X




**Plate**  
3AZT210C 6¾" 16.2cm  
3AZT230C 8" 20.5cm  
3AZT240C 9" 23cm  
3AZT260C 10" 25.4cm



**Plate**  
3AZT270C 10¾" 27cm  
3AZT280C 11½" 29cm  
3AZT290C 12½" 31.8cm



**Plate (decorated rim only)**  
3QVW270C 10¾" 27cm  
3QVW280C 11½" 29cm  
3QVW290C 12½" 31.8cm



**Pizza plate**  
3AZT291X 12¼" 31.1cm



**Soup plate**  
3AZT360C 8½" 21.6cm




**Cream soup cup stacking (handled) (fits 100F)**  
3AZT530U 9¼oz 27cl



**Chefs' bowl**  
3AZT595X 8" 20.3cm 38½oz 109.2cl



**Bud vase**  
3AZT714X



**Sauce dish**  
3AZT811X 3¼" 8.3cm 2¼oz 6.4cl



**Nut dish**  
3AZT768X 3¾" 9.5cm 4¾oz 13.7cl