



Teacup stacking (fits 100B)
3WLC003B 6¼oz 18cl
3WLC002B 8oz 23cl



Tea saucer
3WLC100B



Beaker stacking
3WLC090B 9½oz 27cl



After dinner cup stacking (fits 120B)
3WLC050B 4oz 10cl



After dinner saucer
3WLC120B



Plate
3WLC210B 6½" 16.5cm
3WLC230B 8¾" 21.3cm
3WLC240B 9" 22.9cm
3WLC260B 10" 25.4cm



Plate
3WLC270B 10¾" 27cm
3WLC280B 11¾" 29.6cm



Oval platter
3WLC440B 12½" 31.8cm



Soup plate
3WLC360B 8½" 21.6cm



Cream soup stacking (handled) (fits 100B)
3WLC530B 9½oz 27cl



Soup bowl stacking (unhandled) (fits 100B)
3WLC599B 9½oz 27cl



Oatmeal rimmed
3WLC330B 6½" 16.5cm 11¼oz 31.7cl



Fruit
3WLC300B 5¾" 13.7cm 5½oz 15.6cl



Bouillon/sugar stacking
3WLC500B 8oz 23cl



Jug
3WLC615B 5¼oz 15cl
3WLC625B 9oz 25cl



Teacup stacking (fits 100B)
3CHT003B 6¼oz 18cl
3CHT002B 8oz 23cl



Tea saucer
3CHW100B



Beaker stacking
3CHT090B 9½oz 27cl



After dinner cup stacking (fits 120B)
3CHT050B 4oz 10cl



After dinner saucer
3CHT120B



Plate
3CHT210B 6½" 16.5cm
3CHT230B 8¾" 21.3cm
3CHT240B 9" 22.9cm
3CHT260B 10" 25.4cm



Plate
3CHW270B 10⅝" 27cm
3CHW280B 11⅞" 29.6cm



Oval platter
3CHT440B 12½" 31.8cm



Soup plate
3CHT360B 8½" 21.6cm



Cream soup stacking (handled) (fits 100B)
3CHT530B 9½oz 27cl



Soup bowl stacking (unhandled) (fits 100B)
3CHT599B 9½oz 27cl



Oatmeal rimmed
3CHT330B 6½" 16.5cm 11¼oz 31.7cl



Fruit
3CHT300B 5⅝" 13.7cm 5½oz 15.6cl



Bouillon/sugar stacking
3CHT500B 8oz 23cl



Jug
3CHT615B 5¼oz 15cl
3CHT625B 9oz 25cl