



Tea saucer
3PLW101X



Espresso (fits 121X)
3PLW050F 3oz 9cl



Café au lait saucer
3PLW145X 6³/₈" 16.4cm



Cappuccino (fits 101X)
3PLW001F 8oz 23cl



Caffè latte (fits 145X)
3PLW070F 10oz 28cl



Caffè latte grande (fits 144X)
3PLW076F 15oz 43cl



After dinner saucer
3PLW121X



Café au lait saucer
3PLW144X 7" 17.8cm




Plate
3PLW210F2 6¹/₄" 15.9cm
3PLW220F2 7" 18cm
3PLW230F2 8" 20.3cm
3PLW240F2 9" 23cm





Plate
3PLW260F2 10" 25.4cm
3PLW270F2 10⁵/₈" 27cm
3PLW280F2 11¹/₈" 29.5cm




Profile plate
3PLW296F 11³/₈" 29cm



Deep plate/bowl
3PLW215F 6³/₈" 16.2cm 15oz 42.5cl



Deep plate round
3PLW255F 9¹/₂" 24cm
3PLW285F 11¹/₂" 29.4cm



Oval platter
3PLW419F 8¹/₂" 21.6cm
3PLW439F 11¹/₈" 29.6cm
3PLW449F 13¹/₂" 34.5cm



Deep oval bowl
3PLW405F 6¹/₂" 16.5cm 17oz 48.2cl
3PLW415F 8" 20.3cm 35oz 99.2cl



Deep oval plate
3PLW425F 10¹/₂" 26.7cm
3PLW445F 12¹/₂" 31.8cm



Gourmet bowl
3PLW384F 10" 25.4cm
3PLW385F 12¹/₄" 31.1cm



Bouillon/sugar
3PLW500F 7¹/₄oz 20.9cl



Bowl
3PLW599A 5" 13cm 11³/₈oz 32.3cl
3PLW572F 6³/₈" 16.2cm 20¹/₄oz 57.4cl
3PLW571F 8" 20.3cm 35¹/₂oz 100.5cl