





**Teacup stacking (fits 100F)**  
3MAK001U 6¼oz 18cl  
3MAK002U 8oz 23cl



**Tea/breakfast saucer**  
3MAK100F



**Café au lait saucer**  
3MAK101X



**Plate (decorated rim only)**  
3QVT270C 10⅝" 27cm  
3QVT280C 11½" 29cm  
3QVT290C 12½" 31.8cm



**Oatmeal/salad bowl**  
3MAK337X 6½" 16.5cm 16¼oz 46.1cl



**Teacup low (fits 101X)**  
3MAK037X 7½oz 21cl



**After dinner cup stacking (fits 121X)**  
3MAK050U 3½oz 10cl



**After dinner cup (fits 121X)**  
3MAK060X 3¼oz 9.5cl




**Café au lait cup (fits 101X)**  
3MAK099X 11oz 31cl




**After dinner saucer**  
3MAK121X



**Plate**  
3MAK210C 6⅝" 16.2cm  
3MAK230C 8" 20.5cm  
3MAK240C 9" 23cm  
3MAK260C 10" 25.4cm




**Plate**  
3MAK270C 10⅝" 27cm  
3MAK280C 11½" 29cm  
3MAK290C 12½" 31.8cm



**Plate (decorated rim only)**  
3QVT210C 6⅝" 16.2cm  
3QVT230C 8" 20.5cm  
3QVT240C 9" 23cm  
3QVT260C 10" 25.4cm



**Pizza plate**  
3MAK291X 12¼" 31.1cm



**Soup plate**  
3MAK360C 8½" 21.6cm



**Cream soup cup stacking (handled) (fits 100F)**  
3MAK530U 9¼oz 27cl



**Soup bowl (unhandled)**  
3MAK591X 11oz 31cl




**Chefs' bowl**  
3MAK595X 8" 20.3cm 38¼oz 109.2cl



**Bud vase**  
3MAK714X



**Sauce dish**  
3MAK811X 3¼" 8.3cm 2¼oz 6.4cl



**Nut dish**  
3MAK768X 3¾" 9.5cm 4¾oz 13.7cl