



Teacup stacking (fits 100T)
2TUW005T 6¼oz 18cl



Teacup stacking (fits 100T)
2TUW006T 8oz 23cl



Espresso cup (fits 120T)
2TUW060T 3½oz 10cl



Bowl cup (fits 100T)
2TUW037T 7½oz 21cl



Breakfast cup (fits 100T)
2TUW095T 11oz 31cl



Tea saucer
2TUW100T 5¾" 14.8cm



After dinner cup stacking (fits 120T)
2TUW054T 3oz 9cl



After dinner saucer
2TUW120T 5" 12.8cm



Beaker stacking (fits 100T)
2TUW091T 11oz 31cl




Plate wide rim
2TUW210T 6¾" 16.2cm
2TUW230T 8" 20.3cm
2TUW240T 9¾" 23.3cm
2TUW260T 10" 25.4cm




Plate wide rim
2TUW270T 10¾" 27cm
2TUW280T 11¾" 29cm
2TUW290T 12¾" 32cm





Plate
2TUW217X 6¾" 16cm
2TUW237X 8¾" 22.6cm
2TUW276X 10½" 26.7cm
2TUW288X 11¾" 28.4cm



Oval platter
2TUW400T 8¾" 21.3cm
2TUW430T 11¼" 28.6cm
2TUW440T 12½" 31.8cm



Soup plate
2TUW360T 8½" 21.6cm



Soup/pasta plate
2TUW380X 11¾" 29cm
2TUW385X 12¼" 31.1cm



Soup cup (handled) (fits 100T)
2TUW530T 10oz 28cl



Soup cup (unhandled) (fits 100T)
2TUW599T 10oz 28cl



Oatmeal rimless
2TUW331T 6³/₈" 16.2cm 15¹/₂oz 44cl



Gourmet bowl
2TUW389T 10" 25.4cm
2TUW390T 12¹/₄" 31.1cm



Deep oval bowl
2TUW406X 6¹/₂" 16.5cm 17¹/₂oz 49.6cl
2TUW415X 8⁷/₈" 21.5cm 33oz 93.5cl



Coffee pot
2TUW661T 10¹/₂oz 30cl
2TUW666T 21oz 60cl



Teapot
2TUW647T 13¹/₄oz 38cl
2TUW652T 23oz 65cl



Jug
2TUW616T 4¹/₂oz 15cl
2TUW626T 9oz 25cl



Sauceboat
2TUW807T 11oz 31cl



Eggcup footless
2TUW738T



Square dish
2TUW818T 4¹/₄" 10.8cm



Butter dish/coaster
2TUW736T 4¹/₄" 10.8cm

