




Teacup (fits 101P & 102P)
2PRW002P 7oz 20cl



Cappuccino (fits 101P & 102P)
2PRW001P 8oz 23cl



Saucer
2PRW101P 6¼" 15.9cm



Banquet saucer
2PRW102P 6½" 16.5cm



Espresso (fits 120P)
2PRW050P 2½oz 7.5cl



Espresso saucer
2PRW120P 5" 12.7cm



Mug
2PRW092P 9¾oz 28.8cl



Plate
2PRW210P 6¾" 16.2cm
2PRW240P 9" 22.9cm
2PRW270P 10¾" 27cm
2PRW280P 11¾" 29.7cm



Banquet Plate
2PRW271P 10¾" 27cm



Plate
2PRW283P 11¾" 29.7cm
(with 5" 12.7cm well)




Plate
2PRW284P 11¾" 29.7cm
(with 6" 15.2cm well)



Service plate
2PRW290P 12½" 31.8cm



Profile plate
2PRW297P 11½" 29.4cm



Deep plate
2PRW285P 11¾" 29.7cm
(with 5" 12.7cm well)



Deep plate
2PRW286P 11¾" 29.7cm
(with 6" 15.2cm well)



Plate (with lip)
2PRW287P 11¾" 29.7cm
(with 6" 15.2cm well)

continued overleaf:



Deep Plate (with lip)
2PRW288P 11¾" 29.7cm
(with 6" 15.2cm well)



Soup cup (handled)
2PRW530P 9¾oz 28.8cl



Gourmet bowl
2PRW387P 11⅞" 30cm



Bowl
2PRW551P 3" 7.6cm 3¾oz 10.6cl



Bowl
2PRW552P 4" 10.1cm 7¾oz 21.7cl



Bowl
2PRW553P 4¾" 12.1cm 11¼oz 32.2cl



Bowl
2PRW554P 5½" 14cm 16¼oz 46.3cl



Teapot
2PRW645P 13oz 38cl
2PRW650P 21oz 60cl



Coffee Pot
2PRW665P 10oz 28cl
2PRW670P 23oz 65cl



Creamer
2PRW600P 2½oz 7cl



Jug
2PRW615P 5oz 15cl
2PRW625P 8oz 23cl



Sugar Bowl
2PRW500P 8oz 23cl



Sugar Bowl Cover
2PRW830P



Salt
2PRW704P
Pepper
2PRW705P



Tray
2PRW821P 8⅞" 22.5cm

