



**Teacup stacking (fits 100F)**  
3SFE001U 6¼oz 18cl  
3SFE002U 8oz 23cl



**Teacup low (fits 101X)**  
3SFE037X 7½oz 21cl




**Café au lait saucer**  
3SFE101X



**Plate (decorated rim only)**  
3QVU270C 10⅝" 27cm  
3QVU280C 11½" 29cm  
3QVU290C 12½" 31.8cm



**Oatmeal/salad bowl**  
3SFE337X 6½" 16.5cm 16¼oz 46.1cl



**After dinner cup stacking (fits 121X)**  
3SFE050U 3½oz 10cl



**After dinner cup (fits 121X)**  
3SFE060X 3½oz 9.5cl




**Café au lait cup (fits 101X)**  
3SFE099X 11oz 31cl




**Tea/breakfast saucer**  
3SFE100F



**After dinner saucer**  
3SFE121X




**Plate**  
3SFE210C 6⅝" 16.2cm  
3SFE230C 8" 20.5cm  
3SFE240C 9" 23cm  
3SFE260C 10" 25.4cm



**Plate**  
3SFE270C 10⅝" 27cm  
3SFE280C 11½" 29cm  
3SFE290C 12½" 31.8cm



**Plate (decorated rim only)**  
3QVU210C 6⅝" 16.2cm  
3QVU230C 8" 20.5cm  
3QVU240C 9" 23cm  
3QVU260C 10" 25.4cm



**Pizza plate**  
3SFE291X 12¼" 31.1cm



**Soup plate**  
3SFE360C 8½" 21.6cm



**Cream soup cup stacking (handled) (fits 100F)**  
3SFE530U 9¼oz 27cl




**Soup bowl (unhandled)**  
3SFE591X 11oz 31cl




**Chefs' bowl**  
3SFE595X 8" 20.3cm 38½oz 109.2cl



**Bud vase**  
3SFE714X



**Sauce dish**  
3SFE811X 3¼" 8.3cm 2¼oz 6.4cl



**Nut dish**  
3SFE768X 3¾" 9.5cm 4¾oz 13.7cl