





**Teacup stacking (fits 100F)**  
3SNA001U 6¼oz 18cl  
3SNA002U 8oz 23cl




**Teacup low (fits 101X)**  
3SNA037X 7½oz 21cl



**Café au lait saucer**  
3SNA101X



**Plate (decorated rim only)**  
3QVR270C 10⅝" 27cm  
3QVR280C 11½" 29cm  
3QVR290C 12½" 31.8cm




**Oatmeal/salad bowl**  
3SNA337X 6½" 16.5cm 16¼oz 46.1cl




**After dinner cup stacking (fits 121X)**  
3SNA050U 3½oz 10cl




**After dinner cup (fits 121X)**  
3SNA060X 3½oz 9.5cl



**Café au lait cup (fits 101X)**  
3SNA099X 11oz 31cl




**Tea/breakfast saucer**  
3SNA100F




**After dinner saucer**  
3SNA121X



**Plate**  
3SNA210C 6¾" 16.2cm  
3SNA230C 8" 20.5cm  
3SNA240C 9" 23cm  
3SNA260C 10" 25.4cm



**Plate**  
3SNA270C 10⅝" 27cm  
3SNA280C 11½" 29cm  
3SNA290C 12½" 31.8cm



**Plate (decorated rim only)**  
3QVR210C 6¾" 16.2cm  
3QVR230C 8" 20.5cm  
3QVR240C 9" 23cm  
3QVR260C 10" 25.4cm




**Pizza plate**  
3SNA291X 12¼" 31.1cm



**Soup plate**  
3SNA360C 8½" 21.6cm



**Cream soup cup stacking (handled) (fits 100F)**  
3SNA530U 9½oz 27cl




**Soup bowl (unhandled)**  
3SNA591X 11oz 31cl




**Chefs' bowl**  
3SNA595X 8" 20.3cm 38½oz 109.2cl



**Bud vase**  
3SNA714X



**Sauce dish**  
3SNA811X 3¼" 8.3cm 2¼oz 6.4cl



**Nut dish**  
3SNA768X 3¾" 9.5cm 4¾oz 13.7cl