



Teacup (fits 102X)
2TWT025X 7½oz 21cl



Café au lait cup (fits 102X)
2TWT098X 12oz 34cl



Teacup stacking (fits 102X)
2TWT019X 7oz 20cl



Espresso cup stacking (fits 122X)
2TWT068X 3oz 9cl



Plate
2TWT272X 10½" 27cm
2TWT282X 11" 27.9cm
2TWT291X 11½" 30cm



Tea saucer
2TWT102X 6¼" 16cm



Espresso saucer
2TWT122X 5½" 13cm



Mug
2TWT094X 10oz 28cl




Plate
2TWT212X 6¾" 16.2cm
2TWT234X 8" 20.3cm
2TWT242X 9" 22.9cm



Oval plate
2TWT442X 13¾" x 10½"
35.2cm x 27.9cm



Soup plate
2TWT366X 8¾" 22.5cm



Soup cup stacking (unhandled) (fits 102X)
2TWT599X 10oz 28cl



Oatmeal
2TWT334X 6½" 16.5cm 11oz 31.2cl



Fruit
2TWT310X 5¼" 13.5cm 3¾oz 10.6cl



Bowl (fits 102X)
2TWT589X 10oz 28cl



Gourmet bowl
2TWT392X 9¾" 25.1cm
2TWT393X 11½" 28.3cm



Teapot
2TWT646X 18oz 51cl
2TWT645X 21oz 60cl



Coffee pot
2TWT660X 20oz 56cl



Jug
2TWT615X 3oz 9cl
2TWT625X 5oz 14cl
2TWT626X 9oz 25cl



Creamer
2TWT601X 1½oz 4cl



Sugar/bouillon
2TWT502X 7oz 20cl