



Teacup low (fits 100G)
2VEC011G 7½oz 21cl

Teacup stacking (fits 100G)
2VEC003X 7oz 20cl

Tea saucer
2VEC100G

After dinner can (fits 120G)
2VEC050G 4½oz 13cl



After dinner can stand
2VEC120G

Plate
2VEC210G 6¾" 16.2cm
2VEC230G 8" 20.3cm
2VEC240G 9" 22.9cm
2VEC260G 10" 25.4cm

Plate
2VEC270G 10¾" 27cm
2VEC280G 11¾" 29cm
2VEC290G 12¾" 32cm

Soup plate
2VEC360G 8½" 21.6cm



Oval tray salad
2VEC821G 9" x 5¾" 22.9cm x 14.6cm

Soup cup (handled) (fits 140G)
2VEC530G 10oz 28cl

Soup cup (unhandled) (fits 140G)
2VEC599G 10oz 28cl

Soup cup stand
2VEC140G 6½" 16.5cm



Oatmeal
2VEC330G 6¾" 16.2cm 15oz 42.5cl

Fruit
2VEC300G 4¾" 12.4cm 6¼oz 17.9cl

Coffee pot
2VEC660G 10½oz 30cl
2VEC665G 21oz 60cl

Teapot
2VEC645G 13½oz 38cl
2VEC650G 23oz 65cl



Jug
2VEC615G 5¼oz 15cl
2VEC625G 9oz 25cl

Bouillon/sugar
2VEC500G 3¾" 10cm 7½oz 21cl

Salt
2VEC704G
Pepper
2VEC705G

Bud vase
2VEC714G