



**Teacup low (fits 100G)**  
2CHX011G 7½oz 21cl




**Teacup stacking (fits 100G)**  
2CHX003X 7oz 20cl



**Tea saucer**  
2CHX100G



**Teacup can (fits 101G)**  
2CHX002G 7oz 20cl




**Teacup can stand**  
2CHX101G




**After dinner can (fits 120G)**  
2CHX050G 4½oz 13cl



**After dinner can stand**  
2CHX120G



**Plate wide rim**  
2CHX210G 6¾" 16.2cm  
2CHX230G 8" 20.3cm  
2CHX240G 9" 22.9cm  
2CHX260G 10" 25.4cm



**Plate wide rim**  
2CHX270G 10¾" 27cm  
2CHX280G 11¾" 29cm  
2CHX290G 12¾" 32cm



**Oval platter**  
2CHX445G 14" 35.6cm



**Oval tray salad**  
2CHX821G 9" x 5¾" 22.9cm x 14.6cm



**Soup plate**  
2CHX360G 8½" 21.6cm



**Soup/pasta plate**  
2CHX380G 11¾" 30cm



**Soup cup (handled) (fits 140G)**  
2CHX530G 10oz 28cl



**Soup cup (unhandled) (fits 140G)**  
2CHX599G 10oz 28cl



**Soup cup stand**  
2CHX140G 6½" 16.5cm



**Oatmeal**  
2CHX330G 6<sup>3</sup>/<sub>8</sub>" 16.2cm 15oz 42.5cl



**Fruit**  
2CHX300G 4<sup>7</sup>/<sub>8</sub>" 12.4cm 6<sup>1</sup>/<sub>4</sub>oz 17.9cl



**Coffee pot**  
2CHX660G 10<sup>1</sup>/<sub>2</sub>oz 30cl  
2CHX665G 21oz 60cl



**Teapot**  
2CHX645G 13<sup>1</sup>/<sub>2</sub>oz 38cl  
2CHX650G 23oz 65cl



**Jug**  
2CHX615G 5<sup>1</sup>/<sub>4</sub>oz 15cl  
2CHX625G 9oz 25cl  
2CHX635G 21oz 60cl



**Sugar/soup bowl (fits 100G)**  
2CHX500G 3<sup>3</sup>/<sub>8</sub>" 10cm 7<sup>1</sup>/<sub>2</sub>oz 21cl



**Salt**  
2CHX704G  
**Pepper**  
2CHX705G



**Bud vase**  
2CHX714G

