



Teacup low (fits 100G)
2CHX011G 7½oz 21cl




Teacup stacking (fits 100G)
2CHX003X 7oz 20cl



Tea saucer
2CHX100G



Teacup can (fits 101G)
2CHX002G 7oz 20cl



Teacup can stand
2CHX101G



After dinner can (fits 120G)
2CHX050G 4½oz 13cl



After dinner can stand
2CHX120G



Plate wide rim
2CHX210G 6¾" 16.2cm
2CHX230G 8" 20.3cm
2CHX240G 9" 22.9cm
2CHX260G 10" 25.4cm



Plate wide rim
2CHX270G 10¾" 27cm
2CHX280G 11¾" 29cm
2CHX290G 12¾" 32cm



Oval platter
2CHX445G 14" 35.6cm



Oval tray salad
2CHX821G 9" x 5¾" 22.9cm x 14.6cm



Soup plate
2CHX360G 8½" 21.6cm



Soup/pasta plate
2CHX380G 11¾" 30cm



Soup cup (handled) (fits 140G)
2CHX530G 10oz 28cl



Soup cup (unhandled) (fits 140G)
2CHX599G 10oz 28cl



Soup cup stand
2CHX140G 6½" 16.5cm



Oatmeal
2CHX330G 6³/₈" 16.2cm 15oz 42.5cl



Fruit
2CHX300G 4⁷/₈" 12.4cm 6¹/₄oz 17.9cl



Coffee pot
2CHX660G 10¹/₂oz 30cl
2CHX665G 21oz 60cl




Teapot
2CHX645G 13¹/₂oz 38cl
2CHX650G 23oz 65cl



Jug
2CHX615G 5¹/₄oz 15cl
2CHX625G 9oz 25cl
2CHX635G 21oz 60cl



Sugar/soup bowl (fits 100G)
2CHX500G 3³/₈" 10cm 7¹/₂oz 21cl



Salt
2CHX704G
Pepper
2CHX705G



Bud vase
2CHX714G

